

Botron B8305 Technical Data Sheet



Overview:

Botron's ESD floor cleaner when used regularly will prevent ESD flooring from losing its electrical. Routine maintenance of ESD treated floors with Botron's Easy Clean is recommended to uphold the integrity and longevity of your ESD floor. It is quick drying and leaves no need for rinsing.

Product Notes and Features

- Quick Drying
- Restores Floor Conductivity
- Lead-Free RoHS Compliant

ESD USAGE

Use once (or as needed) per week in light trafficked areas.
Use 1 - 2 times (or as needed) per week in heavy trafficked areas.
Mix 1/2 to two ounces with one gallon of water, depending on the soil level.

PART NUMBERS

B8301 ESD floor cleaner 1 gallon
B8305 ESD floor cleaner 5 gallon



Botron Company Inc. | 325 W. Melinda Ln Phoenix AZ 85027 | Ph# 623-582-6700 | Fax# 623-582-6776

Disclaimer. All statements of technical information are believed to be true and are based upon tests we believe to be reliable. The proper use and application for this product must be the responsibility of the user. The statements herein shall have no force or effect.