

**Liberty Industries, Inc.**

133 Commerce St.  
East Berlin, CT 06023-1106 Us  
Phone: 800-828-5656  
Fax: 860-828-8879  
Toll-free: (800) 828-5656  
Email: libind@liberty-ind.com  
Website: <http://www.liberty-ind.com>

---

**Item # AS-5, AS-5 Vacuum**



**AS-5 Vacuum**

Use to connect shoe cleaner where central vacuum is not available. This new addition to our vacuum line, AS-5 HEPA (dry recovery) System is excellent. It is ready to use and includes a tool kit. The convenient design allows easy access to HEPA filter while maintaining leak proof seal. It features a 4 stage filtration system: paper filter bag, cloth prefilter, HEPA filter and foam exhaust filter. Rated at only 59 dBA users are excited about this new 3 gallon capacity, light weight - only 17 pound vacuum. It is a 96 CFM, 1000 watts unit with a 33' long power cord."

---

**SPECIFICATIONS**

W Size	14 Inch
H Size	17 Inch
L Size	14 Inch
Weight	17 lbs