

Liberty Industries, Inc.

133 Commerce St.
East Berlin, CT 06023-1106 Us
Phone: 800-828-5656
Fax: 860-828-8879
Toll-free: (800) 828-5656
Email: libind@liberty-ind.com
Website: http://www.liberty-ind.com

Item # 800030 (18x36), Tacky Mat® 800030

List Price QUOTE



Tacky Mat® 800030

Get maximum protection with the Tacky Mat (R) 800030 series for foot borne contamination. Each sheet has a strong adhesive coating that removes dirt on contact. The 800030 Series Tacky Mat(R) provides the most economical way to meet cleanroom needs. The Tacky Mat&(R) series; 800030 protects sanitary conditions in cleanroom areas. Each mat consists of 30 disposable sheets. When the top sheet becomes soiled, simply peel off to expose a new, clean surface, Tacky Mat(R); 800030 installs in seconds and can last up to weeks at a time depending on the amount of traffic. No frame is required; adhesive strips, 800030B, or full width backingm 800030BFW, adhere the Tacky Mat(R); 800030 in place on the floor.

- Polyethylene 2 mil sheet, non-allergenic, non-odorous, non-drying solid adhesive, will not age
- Standard color: blue - other colors available on request
- 3 strips of double coated tape or full width adhesive backing
- Each sheet individually tabbed with exclusive pull-tab system
- Anti-microbial germicide in all mats
- 4 mats per case, 30 sheets per mat
- For full width adhesive backing add the suffix FW
- To indicate tack level add A-high, B-medium/ul> USA MADE!

SPECIFICATIONS

Nominal Size	18x36 Inch
Actual Tape Size	18x34x 5/64 Inch
Est. Shipping Wt.	7 lbs.
Tack Grade	A high B moderate