





# **Directions:**

Open foil packet, unfold the Staticide® wipe, and polish surface for maximum cleaning and static control. If streaking occurs, allow wipe to partially dry and wipe surface again. Do not use wipes directly on computer screens. Only wipe plastic housings around the screen. Use Staticide MFCI for screen cleaning.

## Note:

In the state of California, Staticide® wipes are for industrial purposes only. Material Safety Data Sheets are available at www.aclstaticide.com.

### Product #SW12:

24 individually wipes per box; 12 per case **Product #2450:** 

450 individually wrapped wipes per case (no retail packaging)



# SW12 Staticide<sup>®</sup> Anti-Static Wipes

# One-step solution for cleaning and static control

Staticide® wipes are the ideal anti-static choice for keeping electronics and equipment clean and static-free. Staticide wipes have the same long-lasting protection against static as Staticide topical liquids and offer a one-step, convenient cleaning and static-control solution.

Staticide topicals and wipes are not dependent on humidity to be effective. They meet MIL-B-81705 for static decay even in dry conditions and low humidity. Anti-static wipes are safe to use around sensitive electronics for preventing dust buildup and dust attraction. Use on the plastic housing on computer and laptops for keeping screens cleaner longer. Staticide wipes are also ideal for decaying and preventing static on industrial machinery, parts, and in tight spaces, such as keyboards.

## Ideal for the following applications:

- Electronics
- Office equipment
- Lab equipment

## **FEATURES:**

- Quick dry time
- Long-lasting
- Non-toxic
- Prevents dust attraction
- **8** Size: 5" x 8"



840 W. 49th Place · Chicago, IL 60609 800.782.8420 · 847.981.9212 · fax 847.981.9278 info@aclstaticide.com · www.aclstaticide.com

