

Botron B8018 Technical Data Sheet



Overview:

Botron's B8018 Static Dissipative Rubber and Vinyl Mat Cleaner is designed and formulated to clean table mat surfaces to ensure that all insulative dirt and other contaminants are removed. Botron offers two sizes; 6oz and 1qt spray bottle.

PROPERTIES

SPECIFICATIONS

Appearance:	Transparent
Odor:	Slight/floral
Solubility:	Water, alcohols, acetone
pH:	Neutral
Flammability:	Non-flammable
Surface Resistance:	<108
Static Decay:	<.01
Size:	6 ounce or 1 quart
Spray:	Yes
CFC:	None
Alkali:	None
Ammonia:	None

PART NUMBERS

B8011 6oz Spray Bottle
B8018 1qt Spray Bottle

Product Notes and Features

- Static Dissipative
- Rubber Streak Resistant
- Fast Drying
- Non-aerosol



Botron Company Inc. | 325 W. Melinda Ln Phoenix AZ 85027 | Ph# 623-582-6700 | Fax# 623-582-6776

Disclaimer. All statements of technical information are believed to be true and are based upon tests we believe to be reliable. The proper use and application for this product must be the responsibility of the user. The statements herein shall have no force or effect.

GROUNDING

A good ESD static control program starts with a good daily mat cleaning program. Spray Cleanstat Static Dissipative Rubber and Vinyl Mat Cleaner over an area to be cleaned and with a clean lint-free cloth, wipe the surface until dry. For set-in stains, let stand for a few seconds (30) and wipe clean. Cleanstat can be used on keyboards and some CRTs with a lint free cloth. Use swabs for tight areas. S20.20 paragraph 5.3.1.14; periodic cleaning is recommended along with testing as part of your full ESD static control program.

Botron Company Inc. | 325 W. Melinda Ln Phoenix AZ 85027 | Ph# 623-582-6700 | Fax# 623-582-6776

Disclaimer. All statements of technical information are believed to be true and are based upon tests we believe to be reliable. The proper use and application for this product must be the responsibility of the user.

The statements herein shall have no force or effect.