

# Botron B8203 Technical Data Sheet



## Overview:

Botron's B8203 High Quality Lightweight Portable Wrist Strap tester has a large 3/4" touch button for easy testing and easy to read LEDs that show low, high and pass. Audible alarm will sound when passing. Works on all standard wrist straps and coil cords. Test ranges from 725k-10megohms.

## Product Notes and Features

- Lightweight
- Portable
- Good for field kits
- LED Light Indicators

## PROPERTIES

## SPECIFICATIONS

LED:	3 lights
Low Battery:	LED light
Battery:	9 volts
Weight:	5.1 oz.
Size:	3.5" x 4.5" x 1.5"
Test Range:	>725k - 10megohm
Accuracy Range:	+/- 10% Hi 20% Low

## PART NUMBERS

**B8203** Portable Wrist Strap Tester



Botron Company Inc. | 325 W. Melinda Ln Phoenix AZ 85027 | Ph# 623-582-6700 | Fax# 623-582-6776

**Disclaimer.** All statements of technical information are believed to be true and are based upon tests we believe to be reliable. The proper use and application for this product must be the responsibility of the user. The statements herein shall have no force or effect.

## OPERATION

Unscrew two screws on back of unit and insert 9v battery into compartment.

To test wrist straps, plug in banana jack from coil cord into banana jack input on front and press test button.

To test coil cords, unplug coil cord from strap, plug in banana jack. Holding snap end in hand, touch metal coil to the test button and press down.

Botron Company Inc. | 325 W. Melinda Ln Phoenix AZ 85027 | Ph# 623-582-6700 | Fax# 623-582-6776

**Disclaimer.** All statements of technical information are believed to be true and are based upon tests we believe to be reliable. The proper use and application for this product must be the responsibility of the user.

The statements herein shall have no force or effect.