







Product# 7250
ESD blue polypropylene handle
500 swabs per bag / 2 bags per case

Staticide® ESD Microfiber Foam Swab

ESD-safe for critical cleaning

ACL's ESD Microfiber Foam Swab is an exceptional quality swab for the critical cleaning of ESD static-sensitive surfaces. Constructed of medical-grade foam wrapped in microfiber knit, this swab is highly effective in removing and holding liquid or dry contaminants in volume. The rigid ESD handle has a dissipative resistance and will not generate a charge.

The inner foam pad adds increased liquid holding capacity and cushion while microfiber enhances pick-up and can withstand abrasion. These characteristics make it ideal to use with solvents such as acetone, ethanol, IPA, and methanol and for applying or removing lubricants in hard-to-reach areas.

Ideal for the following applications:

- Medical device manufacturing and assembly
- · Electronics manufacturing and assembly
- Nanotechnology
- Automotive
- Aerospace
- Optical lenses and components

FEATURES:

- **⊗** Suitable for ISO Class 4-7 (Class 10–10,000) cleanrooms
- Class 10 laundered; Class 100 packaged
- High solvent capacity
- W Ultra-low particle
- Abrasion resistant
- Blue ESD handle: 108-1010 ohms

SWAB DIMENSIONS:

Product	Total Length	Handle Length	Handle Width	Head Length	Head Width
7250	2.75" (70mm)	2.36" (60mm)	.10" (2.5mm)	.3" (7.4mm)	.16" (4mm)



840 W. 49th Place · Chicago, IL 60609 800.782.8420 · 847.981.9212 · fax 847.981.9278 info@aclstaticide.com · www.aclstaticide.com



ACL Inc. registered to ISO-9001 : 2015 Certificate NO. 10002746