

# 8111 Staticide<sup>®</sup> Economy Wrist Straps



Product# 8111



Product# 8101  
Economy Wrist Strap  
Cord



## *Essential ESD wearables for occasional wear*

ACL's adjustable Economy Wrist Straps offer comfort and secure personal grounding for working in ESD protected areas. Once connected to ground, the Economy Wrist Strap provides a safe connecting path for eliminating static charges.

The flexible, elastic crochet fabric with non-conductive outer lining and conductive inner lining ensures full skin contact around the wrist. Silver conductive fibers are interwoven for maximum conductivity and minimum skin irritation. The Economy Wrist Strap is equipped with a "flip and grip" buckle for a secure adjustable fit. The buckle, comprised of static dissipative nylon, features a hypoallergenic jewelry-grade stainless steel back plate and a 4mm stud.

The Economy Wrist Strap is compatible with ACL's #8101 Economy Wrist Strap Cord. Together, the system provides one to five pounds of breakaway force.

### FEATURES

- ❖ Recommended for occasional wear
- ❖ Lined with 5 rows of double-stitched silver yarn
- ❖ Interior resistance:  $\leq 100$  kohm @ 7-30v dc open circuit
- ❖ Exterior resistance:  $\geq 10$  mohms @ 7-30v dc open circuit
- ❖ 1.5mm band thickness
- ❖ Flat buckle back
- ❖ Dark blue
- ❖ RoHS compliant

Product #8111: Economy Wrist Strap

Product #8101: Economy Wrist Strap Cord

Product #8150: Kit includes #8111 wrist strap,  
#8101 coil cord, and alligator clip

